

DRIVE APRON OVERLAY DETAIL


SR 91

L = EXISTING FLARE WIDTH




SECTION A-A (DRIVE SLOPE TOWARD PAVEMENT)








SECTION A-A (DRIVE SLOPE AWAY FROM PAVEMENT)



SECTION B-B







NOTE (2): THE ESTIMATED QUANTITIES ON THE DRIVE QUANTITY SHEET ARE BASED ON A 5 FT. DISTANCE. TO ENSURE POSITIVE DRAINAGE TOWARD S.R. 91, THE PROJECT ENGINEER SHALL DETERMINE THE LENGTH OF PAVING.

SEE SHEETS <u>22 & 23</u> FOR DRIVE LOCATIONS AND QUANTITIES.



444444444555555555556666 4423456789Ø123456789Ø123