



STATION	ELEVATION	POINT
119	149	
170	282	
70	165	
141	304	
82	173	
146	369	
75	225	
117	426	
51	235	
83	445	
38	245	
65	534	
32	331	

CROSS SECTIONS STA. 212+50 TO STA. 215+00