



STATION	CROSS AREA		VOLUME	
	CUT	FILL	CUT	FILL
239+00	418	0		
238+50			660	0
238+00			378	7
238+50			113	8
237+50			166	63
237+00			66	60
236+50			102	214
236+50			44	171
236+50			73	415
236+50			35	277

CROSS SECTIONS STA. 237+00 TO STA. 239+00