



ELEV.	CROSS AREA		VOLUME	
	OUT	IN	OUT	IN
820	1412	0		
810			2925	0
830				
820	1746	0		
810			3384	0
830				
820			1908	0
810				
830				
820			3852	0
810				
830				
820			2252	0
810				
830				
820			4491	0
810				
830				
820			2598	0
810				
830				
820			2379	0
810				
830				
820			971	0
810				
830				
800			251	0

S.R. 528... CROSS SECTIONS... STA. 47+50 TO STA. 50+00