



OVERHEAD SIGNING

SUPPORT NUMBER	WORK DESCRIPTION
113	REMOVE EXISTING OVERHEAD SIGNS. ERECT NEW OVERHEAD SIGNS ON EXISTING OVERHEAD SUPPORTS.
121	REMOVE AND REERECT EXISTING OVERHEAD SUPPORT AT PROPOSED STATION. SUPPORT SHALL BE MODIFIED AS SHOWN IN THE ELEVATION VIEW. REMOVE EXISTING OVERHEAD SIGNS. ERECT NEW OVERHEAD SIGNS ON RELOCATED OVERHEAD SUPPORT.
118	REMOVE EXISTING OVERHEAD SUPPORT. REMOVE EXISTING OVERHEAD SIGN. ERECT NEW OVERHEAD SIGN ON NEW OVERHEAD SUPPORT.

Note: Quantities carried to General Summary from sheets 105 & 112

REF. N°S 115 & 116 NOT USED

SEE SHEET No. 118 FOR SIGN LEGEND