



OVERHEAD SIGNING

SUPPORT NUMBER	WORK DESCRIPTION
157, 167	REMOVE AND REERECT EXISTING OVERHEAD SUPPORT AT PROPOSED STATION. SUPPORT SHALL BE MODIFIED AS SHOWN IN THE ELEVATION VIEW. REMOVE EXISTING OVERHEAD SIGNS. ERECT NEW OVERHEAD SIGNS ON RELOCATED OVERHEAD SUPPORT.
163, 171	REMOVE EXISTING OVERHEAD SUPPORT. REMOVE EXISTING OVERHEAD SIGN. ERECT NEW OVERHEAD SIGN ON NEW OVERHEAD SUPPORT.
166, 194	REMOVE EXISTING OVERHEAD SIGN. ERECT NEW OVERHEAD SIGN ON EXISTING OVERHEAD SUPPORT.
197, 198	REMOVE EXISTING OVERHEAD SIGN. ERECT NEW OVERHEAD SIGN ON EXISTING OVERHEAD SUPPORT.
200, 202	REMOVE EXISTING OVERHEAD SIGN. ERECT NEW OVERHEAD SIGN ON EXISTING OVERHEAD SUPPORT.
167	REMOVE AND REERECT EXISTING OVERHEAD SUPPORT AT PROPOSED STATION. REMOVE EXISTING OVERHEAD SIGNS. ERECT NEW OVERHEAD SIGNS ON RELOCATED OVERHEAD SUPPORT.

Note: Quantities carried to General Summary from sheets 106, 107, 112 & 114
REF. NO. 201 & 204 NOT USED
SEE SHEET NO. 116 FOR SIGN LEGEND.