



STATION	AREA	VOLUME
313+00	139	2225
312+50	256	1414
312+00	412	1656
311+50	189	374
311+00	384	494
311+00	220	160
311+00	424	944
311+00	232	860

CROSS SECTIONS STA. 311+50 TO STA. 313+00