


Specifications
for
Temporary Rolled Erosion Control Product




Specifications
for
Temporary Rolled Erosion Control Product

1. Channel/Slope Soil Preparation Grade and compact area of installation, preparing seedbed by loosening 2"-3" of topsoil above final grade. Incorporate amendments such as lime and fertilizer into soil. Remove all rocks, clods, vegetation or other debris so that installed RECP will have direct contact with the soil surface.
 2. Channel/Slope Seeding Apply seed to soil surface prior to installation. All check slots, anchor trenches, and other disturbed areas must be reseeded. Refer to the Permanent Seeding specification for seeding recommendations.
- Slope Installation**
3. Excavate top and bottom trenches (12"x6"). Intermittent erosion check slots (6"x6") may be required based on slope length. Excavate top anchor trench 2' x 3' over crest of the slope.
 4. If intermittent erosion check slots are required, install RECP in 6"x6" slot at a maximum of 30' centers or the mid point of the slope. RECP should be stapled into trench on 12" centers.
 5. Install RECP in top anchor trench, anchor on 12" spacings, backfill and compact soil.
 6. Unroll RECP down slope with adjacent rolls overlapped a minimum of 3". Anchor the seam every 18". Lay the RECP loose to maintain direct soil contact, do not pull taught.
 7. Overlap roll ends a minimum of 12" with upslope RECP on top for a shingle effect. Begin all new rolls in an erosion check slot if required, double anchor across roll every 12".
 8. Install RECP in bottom anchor trench (12"x6"), anchor every 12". Place all other staples throughout slope at 1 to 2.5 per square yard dependant on slope. Refer to manufacturer's anchor guide.
- Channel Installation**
9. Excavate initial anchor trench (12"x6") across the lower end of the project area.
 10. Excavate intermittent check slots (6"x6") across the channel at 30' intervals along the channel.
 11. Excavate longitudinal channel anchor slots (4"x4") along both sides of the channel to bury the edges. Whenever possible extend the RECP 2'-3' above the crest of channel side slopes.
 12. Install RECP in initial anchor trench (downstream) anchor every 12", backfill and compact soil.
 13. Roll out RECP beginning in the center of the channel toward the intermittent check slot. Do not pull taught. Unroll adjacent rolls upstream with a 3" minimum overlap (anchor every 18") and up each channel side slope.
 14. At top of channel side slopes install RECP in the longitudinal anchor slots, anchor every 18".
 15. Install RECP in intermittent check slots. Lay into trench and secure with anchors every 12", backfill with soil and compact.
 16. Overlap roll ends a minimum of 12" with upstream RECP on top for a shingling effect. Begin all new rolls in an intermittent check slot, double anchored every 12".
 17. Install upstream end in a terminal anchor trench (12"x6"), anchor every 12", backfill and compact.
 18. Complete anchoring throughout channel at 2.5 per square yard using suitable ground anchoring devices (U shaped wire staples, metal geotextile pins, plastic stakes, and triangular wooden stakes). Anchors should be of sufficient length to resist pullout. Longer anchors may be required in loose sandy or gravelly soils.

REVISIONS	BY
REVISED GRADING OCT. 2, 2013	WSO

Barrington
CONSULTING GROUP, INC.
9114 TYLER BLVD, MENTOR, OHIO 44060
PHONE 440.205.1260 FAX 440.205.1262
www.BarringtonCGI.com



DETAILS
7540 SARAH LEE DR., CONCORD TWP., OHIO 44077
S/L 32B CALI WOODS No. 2 Vol. 31 Pg. 4
LITTLE MOUNTAIN HOMES, INC.

DRAWN WSO
CHECKED DWN
DATE DEC. 27, 2012
SCALE 1" = 40'
JOB NO. 12022-032B
SHEET 3/3
OF SHEETS